


















## Hardware Included



## Tools you will need






To put your cabinets together you will need the following tools.

 Cordless drill with: • Number 2 Phillips head bit • 4.5mm drill bit • Number 12 countersinking drill bit	 Tape Measure	 Pencil	 Hammer	 Clamps (Quick Release)	 Safety Gear	 Phillips Head Screw Driver
 Spirit Level (900mm recommended)	 Masking Tape	 65mm Wood Screw	 Wall Fixing (If Necessary)			


### Important notice

- Make sure you leave plumbing and electrical work to qualified trades people. Never try this yourself.
- If you have any questions contact us on **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST or email: **info@flatpax.com.au**.

# 600mm 2 DRAWER FLOOR CUPBOARD




## STEP 1




**note:** Make sure the pre-drilled holes for the adjustable feet are facing outwards.


## STEP 2



## STEP 3




## STEP 4




**stop:** If this cabinet is to be installed at the end of the run refer to the kickboard instructions now on the correct placement of the feet. Set the height of the adjustable feet to 145mm to suit the kickboard.

## STEP 5




**note:** The white side of the back panel should face inside the cabinet.


## STEP 6




## STEP 7




## STEP 8




## STEP 9




Remove bracket from metal sided drawer by releasing the screw.




## STEP 10




## STEP 11




## STEP 12




## STEP 13




## STEP 14



## STEP 15




## STEP 16




Drawer fronts can be adjusted up and down via the adjustment screw, and left and right via the elongated holes in the bracket.

## STEP 17




Place masking tape on both sides of the door where holes will be drilled to avoid chipping. Pre-drill using 4.5mm drill bit.

## STEP 18






## STEP 19



Check cabinets are level then clamp together.  
Pre-drill using 2mm drill bit and attach cabinets  
together.

## STEP 20



**Caution:** Please ensure all cabinets  
are screwed into your timber stud wall  
using a minimum of 65mm timber  
screws. If attaching to concrete, brick,  
steel or any other substrates seek  
advice from your hardware specialist.